


15KV 800 Amp KA Style Coupler 15KA Range



Pioneering the Difference.



High Voltage Cable Coupler System Technical Guide



Stock No: (See page 3 for breakdown)

Description: Half Coupler – Unarmoured Cable

Rating: 15kV 800A Material: Aluminium LOA: 26 ³/₁₆" (665mm) Mass: 36 lbs (16kg) Volume: 4.0 Litres



Stock No: (See page 3 for breakdown) **Description:** Adaptor – Gear Mount

Rating: 15kV 800A Material: Aluminium LOA: 18⁷/₈" (480mm) Mass: 36 lbs (16kg) Volume: 4.0 Litres



Stock No: RS844

Description: Insulated End Cover

Rating: 15kV 800A Material: Aluminium Mass: 11 lbs (5kg)



Stock No: RS850

Description: Cast Protection Cover

Rating: 15kV 800A Material: Aluminium Mass: 6.6 lbs (3kg)



Stock No: RS112

Description: Phase Connectors

Rating: 15kV 800A




Stock No: RS117

Description: Earth Pilot Connector



High Voltage Cable Coupler System


Stock Selection Guide - 15kV 800A



	Description	Stock No.	Page
А	Half Coupler – Unarmoured Cable		(refer to page 3)
В	Adaptor – Gear Mount		(refer to page 3)
С	Insulated End Cover	RS844	(refer to page 8)
D	Cast Protection Cover	RS850	
E	Phase Connectors (3 required per join)	RS112	
F	Earth Pilot Connector (1 required per join)	RS117	



High Voltage Cable Coupler System Cable and Gear Mount Equipment






High Voltage Cable Bolted Coupler Unarmoured Gland Assembly


Size 1 Housing

Stock No: RS257



Cable OD	Stock No
3 ¹ / ₂ " (90mm)	RS266
3 ³ / ₈ " (85mm)	RS265
3 ¹ / ₈ " (80mm)	RS264
2 ¹⁵ / ₁₆ " (75mm)	RS263
2 ³ / ₄ " (70mm)	RS262
2 ⁹ / ₁₆ " (65mm	RS261
2 ³ / ₈ " (60mm)	RS260
2 ¹ / ₈ " (55mm)	RS259
1 ¹⁵ / ₁₆ (50mm)	RS478
1 ¾" (45mm)	RS479


Size 2 Housing



Cable ID	Stock No
4 ⁵ / ₈ " (117mm) 4 ⁹ / ₁₆ " (115mm) 4 ⁵ / ₁₆ " (110mm) 4 ¹ / ₈ " (105mm) 3 ¹⁵ / ₁₆ " (100mm) 3 ³ / ₄ " (95mm) 4 ¹⁵ / ₁₆ " (125mm)	RS272 RS271 RS270 RS269 RS268 RS267 RS910
. ,16 (12011111)	1.5010




Adaptor Gear Mount Flange Assemblies





15kV Insulated End Cover



RS844

15kV Universal Insulated End Cover Pilot to ground/Diode/Resistor

Alignment Sticks

RS178 Phase guide stick set for assembly (3 included)

15kV Termination Kit Large

RS323

(to suit core outer diameter $^{15}/_{16}$ "(24mm) – 1 $^{7}/_{8}$ "(48mm)



4.0LCompoud



3 x QT567



CC2

15kV Termination Kit Small

RS406

(to suit core outer diameter $\frac{5}{8}$ "(16mm) – $\frac{11}{8}$ "(28.5mm)



4.0L Compound



Compound



3 x QT5671



CC2

Coupler Tool Kit (All Voltages)

Stock No. RS284

2 off 1246 1 off RS325

1 off RS177

1 off RS176

H

Spanners

Racking Tool

Slide Hammer

Earth Pilot Removal Tool


1 off 1274 = 15 off 1278




Tool Box High Voltage Cleaning Tissues




High Voltage Cable Bolted Coupler Body Assembly 15kV







Adaptor Gear Mount Flange Assembly 15kV with Support Bracket





Coupler Support Stand for 15kV Couplers


Technical Data

Stock No: RS183

Footprint: 1500mm x 950mm

Coupler Height: 390mm Mass: 18kg

Cradle Assembly Stock No: RS351





3 – Way Splitter for 15kV Couplers

Technical Data

Stock No. RS353


Amps: 800

Footprint: 1700mm x 950mm

Volts: 15000

Coupler Height: 390mm

Mass: 108 kg





Coupler Alignment Skid for 15kV Couplers

Technical Data

Footprint: 1900mm x 950mm

Coupler Height: 390mm

Mass: 46 kg

15kV Alignment Skid

Stock No	Description
RS1028	Complete Alignment Skid with 120mm Clamps
RS1029	Complete Alignment Skid with 115mm Clamps
RS1030	Complete Alignment Skid with 110mm Clamps
RS1031	Complete Alignment Skid with 105mm Clamps
RS1032	Complete Alignment Skid with 100mm Clamps
RS1033	Complete Alignment Skid with 95mm Clamps
RS1034	Complete Alignment Skid with 90mm Clamps
RS1035	Complete Alignment Skid with 85mm Clamps


Stock No	Description
RS1036 RS1037 RS1038 RS1039 RS1040 RS1041 RS1042	Complete Alignment Skid with 80mm Clamps Complete Alignment Skid with 75mm Clamps Complete Alignment Skid with 70mm Clamps Complete Alignment Skid with 65mm Clamps Complete Alignment Skid with 60mm Clamps Complete Alignment Skid with 55mm Clamps Complete Alignment Skid with 50mm Clamps
RS1043	Complete Alignment Skid with 45mm Clamps

Stock No: RS349

Cable Clamp

ID Sizes	Stock No
4 ⁵ / ₈ " (120mm)	RS326
4 ⁹ / ₁₆ " (115mm)	RS327
4 ⁵ / ₁₆ " (110mm)	RS328
4 ¹ / ₈ " (105mm)	RS329
3 ¹⁵ / ₁₆ "(100mm)	RS330
3 ¾" (95mm)	RS331
3 ½" (90mm)	RS332
3 ³ / ₈ " (85mm)	RS333
3 ¹ / ₈ " (80mm)	RS334
2 ¹⁵ / ₁₆ "(75mm)	RS335
2 ¾" (70mm)	RS336
2 ⁹ / ₁₆ " (65mm)	RS337
2 ³ / ₈ " (60mm)	RS338
2 ¹ / ₈ " (55mm)	RS339
1 ¹⁵ / ₁₆ " (50mm)	RS480
1¾" (45mm)	RS481

Protection Bars (4 Required)




TM_704 Version 1 31/08/2018 12

Stock No: RS366



Alignment Skid Operations





Stand Operations

FIT RACKING TOOL TO CLOSE OR OPEN COUPLERS

2
CLAMP COUPLER IN CRADLE

3
FULLY INSERT CONNECTORS IN COUPLER WITH SLIDE HAMMER

4
CONNECT COUPLER BY HAND


1
FIT COUPLER IN

TM_704 Version 1 31/08/2018 14


STAND CRADLE



Inserting Connectors and Coupling Operation



AS SHOWN



Coupler Tool Kit (All Voltages) Stock No. RS284

2 off PN:1246 Spanners 1 off RS325 Racking Tool 1 off RS177 Slide Hammer


1 off RS176 Earth Pilot Removal Tool 15 off PN:1278 High Voltage Cleaning Tissues

TM_704 Version 1 31/08/2018



15kV 800A - Unarmoured Coupler


Termination Procedure





15kV 800A Gear Mount Adaptor

Termination Procedure





Care & Maintenance for Open Cut Coupler System

To ensure the safe operation of the mining couplers, personnel should be aware of minimal ongoing care and maintenance.

- When cables are not in use, ensure that a cast protection end cover is fitted that provides edequate sealing against moisture.
- When a witness mark is brightly painted on the sheath, this is located where the cable enters the gland. This needs to be routinely inspected to check if the gap appears between the end of the gland and the witness mark.
- A gap may indicate that the cable has been under tension and that the termination in the coupler may have moved.
- The coupler should never be used as a towing or anchor point.
- Ensure that the connector pins have firm contact pressure or grip on the male pin in the coupler. If grip/ pressure is loose then new connectors are required.
- Before bolting couplers together or before fitting an end cover, ensure that the face sealing ring is located correctly in the grove.
- On each occasion when the couplers are bolted together, inspect the male pin in the coupler for obvious of damage. Also inspect the location on the nylon locking circlip to ensure that it is evenly fitted onto the contact.
- If the circlip appears dislocated or damaged then repairs are necessary. This
 event indicates that the termination in the coupler has been under tension
 as a result of handling.
- On regular intervals of up to 12 months, the tension on the gland housing compression ring needs to be maintained. This process requires that the cable clamp be removed and the four compression ring bolts tensioned.